

PATIENT INSTRUCTIONS

Kinex K3,K4, K4 Xtend™ Knee CPM

To change Extension and Flexion Rotation:

1. Press the **STOP** button.
2. Press the **Extension** and **STOP** buttons at the same time until screen shows << pointing to extension.
3. To change Extension, press the **Extension** button.
4. Press **(+)** to increase and **(-)** to decrease.
5. To change Flexion, press the **Flexion** button.
6. Press **(+)** to increase and **(-)** to decrease.
7. To save the values, press **STOP**.
8. Press **START**.

